FRONT

Skullcandy
USER GUIDE

Vert

Pairing Mode
"Off Mode"

Pair New Device "off Mode
Coupler Nouvel Appareil "mode Off
Vincular Nuevo Dispositivo "modo Apagado
Accoppia Nuovo Dispositivo "modalità Spento
Emparelhar Novo Dispositivo "modo Desligado
Mit Neuem Gerät Koppeln "ausgeschaltetZustand
Nieuw Apparaat Paren "uitmodus
Parzen Ny Enhet "blukket Tilstand
Muodosta Uusi Laitepari "offilä
Sammenkoble Ny Enhet "av-modus
Para Ny Enhet "av-läge
Сопряжение Нового Устройства
"вЫключенное"Режиме
配対新装備 "休眠模式
新しいデバイスをペアリング"オフモード
"새 기기 짝맞추기"끄기 모드
"جهاز جديد مقترن"وضع الإيقاف

Pair New Device
"Vert"

Pairing Mode
Mode Couplage
Modo De Vinculación
Modalità Di Accoppiamento
Modo Emparelhamento
Koppelmodus
Pairmodus
Pardannelsestilstand
Laitoparin Muodostuotila
Sammenkoblingsmodus
Paringsläge
Режим Сопряжения
配対模式
ペアリングモード
쌍이 짝짓 모드
وضع الإقران

Power - On

Power - On/Off
On/Off
Encendido/apagado
Accensione/spegnimento
Ligar/desligar
Ein/aus
Aan/uitzetting
Tænd/sluk For Strøm
Virta Päälläpois
Strøm Av/på
Ström Av/på
Включить/выключить Питание
开机/关机
電源 - On/off
전원 켜기/끄기
تشغيل/إيقاف التشغيل

Power - Off

Power - On/Off
On/Off
Encendido/apagado
Accensione/spegnimento
Ligar/desligar
Ein/aus
Aan/uitzetting
Tænd/sluk For Strøm
Virta Päälläpois
Strøm Av/på
Ström Av/på
Включить/выключить Питание
开机/关机
電源 - On/off
전원 켜기/끄기
تشغيل/إيقاف التشغيل

Play/Pause

Play/pause
Lecture/pause
Reproducir/pausar
Riproduci/pausa
Reproduzir/colocar Em Pausa
Wiedergabe/pause
Afspelen/pauzeren
Alkaa/pause
Toista/tauko
Spill/pause
Spela Upp/pausa
Воспроизведение/пауза
播放/暂停
再生 / 一時停止
재생/일시 정지
تشغيل/إيقاف مؤقت

Volume Up

Volume Up
Volume +
Subir Volumen
Aumento Volume
Aumentar O Volume
Lautstärke Erhöhen
Volume Omhoog
Skru Op For Lydstyrken
Äänenvoimakkuuden Lisäys
Volum Opp
Öka Volumen
Увеличение Громкости
音量增大
音量を上げる
볼륨 높이기
رفع مستوى الصوت

Volume Down

Volume Down
Volume –
Bajar Volumen
Réduisez Volume
Diminuir O Volume
Lautstärke Senken
Volume Omlaag
Skru Ned For Lydstyrken
Äänenvoimakkuuden Vähennys
Volum Ned
Sänka Volymen
Уменьшение Громкости
音量减小
音量を下げる
볼륨 낮추기
خفض مستوى الصوت

Track Forward

Track Forward
Piste Suivante
Adelantar
Brano Successivo
Faixa Seguinte
Nächster Titel
Volgend Nummer
Skift Til Næste Musiknummer
Kaikua Eteenpäin
Neste Spor
Nästa Ljudspår
Переключение На 1 Трек Вперед
上一曲目
次のトラックを再生する
다음 트랙으로
مسار التالي

Track Back

Track Back
Piste Précédente
Retroceder
Brano Precedente
Faixa Anterior
Vorangehender Titel
Vorig Nummer
Musiknummer Tilbage
Kaikua Taaksepäin
Forige Spor
Byta Till Föregående Spår
Переключение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로
مسار التالي

Answer/End

Answer/end
Répondre/fin
Responder/colgar
Risposta/fine
Atender/desligar
Anrufmen/beenden
Beantwoorden/beëindigen
Besvarelse/afslut
Vastaus/lopetus
Svar/avslut
Svara/lägg PÅ
Ответить/закончить
接听/结束
応答 / 終了
전화 받기/끊기
الإجابة

Activate Assistant

Activate Voice Assistant
Active l'assistant vocal
Activar el asistente de voz
Attivare assistente vocale
Ativar assistente de voz
Sprachassistenten aktivieren
Stemhulp activeren
Aktivér tale-assistent
Aktivoi äänistyjen
Aktiver talassistent
Aktivera röstassistent
Активировать голосовой помощник
激活语音助理
ボイスアシスタントをアクティベートする
음성 도우미 기동하기
تنشيط المساعد الصوتي

Activate Tile™ tile

Pair Tile™
Associer Tile™
Empareja Tile™
Abbinare Tile™
Emparelhar Tile™
Tile™ koppeln
Met Tile™ koppelen
Par med Tile™
Muodosta Tile™-laitepari
Sammenkoblamed Tile™
Para Tile™
Ihpareista Tile™
配対 Tile™
Tile™ をペアリングする
타일 연결하기
زوج Tile™

Charge

Charge
Charge
Cargar
Carica
Carregar
Aufladen
Opladen
Oplad
Latausa
Lading
Ladda
Зарядка
充电
充電
충전
شحن

Rapid Charge: 10 minutes = 2 hours

Rapid Charge: 10 minutes = 2 hours
Charge Rapide : 10 minutes = 2 heures
Carga Rápida: 10 minutos = 2 horas
Carica rapida: 10 minuti = 2 ore
Carregamento Rápido: 10 minutos = 2 horas
Schnelles Aufladen: 10 Minuten = 2 Stunden
Snelladen: 10 minuten = 2 uur
Hurtig Opladning: 10 minutter = 2 timer
Pikalataus: 10 minuutta = 2 tuntia
Hurtiglading: 10 minutter = 2 timer
Snabbladdning: 10 minuter = 2 timmar
Быстрая зарядка: 10 минут = 2 часа
快速充电：10 分钟 = 2 小时
高速充電：10 分 = 2 時間
새 창치 짧비한: 10 دقائق = 2 ساعتين

Americas
Skullcandy, Inc.
6301 N Landmark Dr.
Park City, UT 84098, U.S.A.
Skullcandy.com

Canada
Skullcandy Canada ULC
329 Railway St. Unit 205,
Vancouver, BC, V6A 1A4
Canada
Skullcandy.ca

Europe
Skullcandy Europe BV
Postbus 425
5500AK Veldhoven
Nederland
Skullcandy.eu

México
Skullcandy Mexico S de RL de CV
Avisoleles 218
Polanco IV Seccion, Miguel Hidalgo
11560, Mexico City, Mexico
Skullcandy.mx

Japan/日本
Skullcandy Japanお問合わせ
〒150-0001 東京都渋谷区神宮前
5 - 17 - 11 パークサイドオーキド3階
Skullcandy Japanカスタマーサービス
商品についてのお問い合わせはこちら
Skullcandy.jp

BACK

Skullcandy
2 Year Global Warranty

United States of America and Canada Product Purchased Only

EN Skullcandy products are covered by a one year warranty. If Skullcandy sells You a product that is defective in material or workmanship, Skullcandy will repair or replace the product at its discretion, provided that the product is returned to Skullcandy within the warranty period. Skullcandy's obligation to repair or replace a defective product is Your sole remedy. Skullcandy's liability for any defective product does not include any other costs, expenses, or damages, including incidental or consequential damages, or any loss of profits or revenue.

Product Purchased Outside The United States of America and Canada

Warning: To prevent injury, damage, or loss of data or video/audio quality, Skullcandy recommends that You read the following safety information before using Your product. Skullcandy's warranty does not cover any injury, damage, or loss of data or video/audio quality resulting from a failure to follow the following safety information. Skullcandy's warranty does not cover any product that has been used in a manner that is contrary to the following safety information.

Exclusion: Skullcandy's warranty does not cover any product that has been used in a manner that is contrary to the following safety information.

Battery: Do not attempt to remove the battery. Do not puncture, disassemble, or crush the battery. Do not expose the battery to water or other liquids. Do not expose the battery to fire, explosion, or other hazards. Do not short circuit the battery. Do not place the battery in a microwave oven or pressurized container. Do not use the battery if it appears damaged, deformed, or has a leak. Do not use the battery if it has been dropped. Do not use the battery if it has been exposed to extreme temperature. Do not use the battery if it has been exposed to water or other liquids. Do not use the battery if it has been exposed