









NOMAD

LAPTOP BACKPACK

TLL611292-TLL611302

-  User manual
-  Manual de utilizare
-  Manual del usuario
-  Manuel d'utilisation
-  Manuale d'uso
-  Benutzerhandbuch

A silhouette of a city skyline with various skyscrapers, positioned at the bottom of the page.

INTO YOUR FUTURE

Technical specifications

Features: USB charging port, Multiple compartments

Material: Oxford

Available colours: Grey, Black

Laptop size: Up to 15.6"

Product size: 40 cm x 30 cm x 11 cm

Product weight: 660 g

Instructions for using the integrated USB port.

I. Connect the USB port inside the backpack to a portable power bank and place it in an inside pocket.

II. Connect the external USB port on the side to your smartphone using your own charging cable.

ATTENTION

This product is not a toy, please keep it away from children to avoid unnecessary accidents.

Do not twist or crush the USB cable.

Do not use the charging function if the cable or connectors are broken or damaged.

The backpack is not resistant to high temperatures, keep away from heat sources and open flames.

Do not attempt to disassemble or modify the backpack as it may damage or weaken the structural integrity, causing potential property damage or injury.

While the backpack is designed for outdoor use, avoid excessive exposure to extreme weather elements such as heavy rain